



جدول ۵۰: مشخصات ابعادی هواساز افقی نوع L

UNIT SIZE	INSULATION THK. (IN)	A	B	C	D	E	F	G	H	K	L	M	N	P	S
3	1	37	39 1/2	70	28	10	16 1/3	16 4/5	39	19 3/4	31	-	2	35	16 1/3
	2				30 2/3	9	18 1/3	17 4/5							
6	1	54	43 1/2	73	32	18 6/7	16 1/3	16 4/5	56	19 3/4	32 1/2	-	2	36 1/2	16 1/3
	2				34 5/7	17 6/7	18 1/3	17 4/5							
9	1	60 5/8	49 1/4	83 1/2	37 3/4	19 1/3	22	20 4/5	62 5/8	19 3/4	37 3/4	-	2	41 3/4	20 1/3
	2				40 4/9	18 1/3	24	21 4/5							
13	1	69	53 1/7	105 1/2	41 2/3	22 3/8	24 1/4	24 3/4	71	19 3/4	48 3/4	-	2	52 3/4	24 1/4
	2				44 1/3	21 3/8	26 1/4	25 3/4							
16	1	69	57 1/9	114 1/6	45 3/5	20 2/5	28 1/5	28 2/3	71	19 3/4	53	-	2	57	28 1/5
	2				48 1/3	19 2/5	30 1/5	29 2/3							
19	1	78 3/4	70 6/7	114 1/6	59 1/3	23 1/4	32 1/5	32 5/7	80 3/4	23 3/4	53	-	2	57	32 1/5
	2				62	22 1/4	34 1/5	33 5/7							
24	1	88 3/5	53 1/7	130 2/3	41 2/3	28 1/5	32 1/5	32 5/7	90 3/5	23 3/4	55	-	2	65 1/3	32 1/5
	2				44 1/3	27 1/5	34 1/5	33 5/7							
30	1	88 3/5	53 1/7	157 1/2	41 2/3	28 1/5	32 1/5	32 5/7	90 3/5	23 3/4	55	-	2	78 3/4	32 1/5
	2				44 1/3	27 1/5	34 1/5	33 5/7							
36-1	1	102 1/3	62	157 1/2	48 3/5	31 1/9	40 1/6	40 2/3	104 1/3	23 3/4	55	-	3	78 3/4	40 1/6
	2				52 2/5	30 1/9	42 1/6	41 2/3							
36	1	130 1/2	65 1/4	120	51 3/4	22	31 1/2	31 1/2	132 1/2	23 3/4	47 1/4	23 1/2	3	60	32 1/4
	2				55 1/2	21	33 1/2	32 1/2				21 1/2			
40	1	110 1/4	68	165 1/3	54 3/5	35	40 1/6	40 2/3	112 1/4	23 3/4	55	-	3	82 2/3	40 1/6
	2				58 2/5	34	42 1/6	41 2/3							
41	1	131 1/2	67 1/4	131 1/2	53 3/4	22 1/2	31 1/2	31 1/2	133 1/2	23 3/4	47 1/4	23 1/2	3	65 3/4	32 1/4
	2				57 1/2	21 1/2	33 1/2	32 1/2				21 1/2			
48	1	118 1/9	75	177 1/5	61 3/5	37	48 1/9	48 3/5	124	23 3/4	55	-	3	88 3/5	48 1/9
	2				65 2/5	36	50 1/9	49 3/5							
51	1	133 1/2	70 1/2	156	57	17 1/2	37	35 1/2	135 1/2	23 3/4	47 1/4	24 1/2	3	78	36 1/4
	2				60 3/4	16 1/2	39	36 1/2				22 1/2			

از ارتفاع اصلاح شده (C+Z) در جدول صفحه ۶۸ و ۷۷ استفاده کنید. زمانی که واحد رطوبت زن آبی و ایرواشر انتخاب می‌کنید. توجه: برای پیدا کردن ابعاد " = " صفحه ۶۰ را ببینید.