



جدول ۴۶: مشخصات ابعادی کابینت فن FH

UNIT SIZE	INSULATION THK. (IN)	A	B	C*	D	E	F	G	H	K	L	M	N	S
3	1	37	39 1/2	35	28	10	16 1/3	16 4/5	39	19 3/4	31	-	2	16 1/3
	2				30 2/3	9	18 1/3	17 4/5						
6	1	54	43 1/2	36 1/2	32	18 6/7	16 1/3	16 4/5	56	19 3/4	32 1/2	-	2	16 1/3
	2				34 5/7	17 6/7	18 1/3	17 4/5						
9	1	60 5/8	49 1/4	41 3/4	37 3/4	19 1/3	22	20 4/5	62 5/8	19 3/4	37 3/4	-	2	20 1/3
	2				40 4/9	18 1/3	24	21 4/5						
13	1	69	53 1/7	52 3/4	41 2/3	22 3/8	24 1/4	24 3/4	71	19 3/4	48 3/4	-	2	24 1/4
	2				44 1/3	21 3/8	26 1/4	25 3/4						
16	1	69	57 1/9	57	45 3/5	20 2/5	28 1/5	28 2/3	71	19 3/4	53	-	2	28 1/5
	2				48 1/3	19 2/5	30 1/5	29 2/3						
19	1	78 3/4	70 6/7	57	59 1/3	23 1/4	32 1/5	32 5/7	80 3/4	23 3/4	53	-	2	32 1/5
	2				62	22 1/4	34 1/5	33 5/7						
24	1	88 3/5	53 1/7	65 1/3	41 2/3	28 1/5	32 1/5	32 5/7	90 3/5	23 3/4	55	-	2	32 1/5
	2				44 1/3	27 1/5	34 1/5	33 5/7						
30	1	88 3/5	53 1/7	78 3/4	41 2/3	28 1/5	32 1/5	32 5/7	90 3/5	23 3/4	55	-	2	32 1/5
	2				44 1/3	27 1/5	34 1/5	33 5/7						
36-1	1	102 1/3	62	78 3/4	48 3/5	31 1/9	40 1/6	40 2/3	104 1/3	23 3/4	55	-	3	40 1/6
	2				52 2/5	30 1/9	42 1/6	41 2/3						
36	1	130 1/2	65 1/4	60	51 3/4	22	31 1/2	31 1/2	132 1/2	23 3/4	47 1/4	23 1/2	3	32 1/4
	2				55 1/2	21	33 1/2	32 1/2				21 1/2		
40	1	110 1/4	68	82 2/3	54 3/5	35	40 1/6	40 2/3	112 1/4	23 3/4	55	-	3	40 1/6
	2				58 2/5	34	42 1/6	41 2/3						
41	1	131 1/2	67 1/4	65 3/4	53 3/4	22 1/2	31 1/2	31 1/2	133 1/2	23 3/4	47 1/4	23 1/2	3	32 1/4
	2				57 1/2	21 1/2	33 1/2	32 1/2				21 1/2		
48	1	118 1/9	75	88 3/5	61 3/5	37	48 1/9	48 3/5	124	23 3/4	55	-	3	48 1/9
	2				65 2/5	36	50 1/9	49 3/5						
51	1	133 1/2	70 1/2	78	57	17 1/2	37	35 1/2	135 1/2	23 3/4	47 1/4	24 1/2	3	36 1/4
	2				60 3/4	16 1/2	39	36 1/2				22 1/2		
56	1	118 1/9	75	102 2/5	61 3/5	35	48 1/9	48 3/5	120 1/9	23 3/4	60	-	3	48 1/9
	2				65 2/5	34	50 1/9	49 3/5						
63	1	142 1/2	68	97 3/4	54 1/2	16 3/4	40	46	144 1/2	23 3/4	63 3/4	29	3	48
	2				58 1/4	15 3/4	42					27		
70	1	126	80	116 1/7	66 3/5	37	52	52 1/2	128	31 1/2	60	-	18 2/5	52
	2				70 2/5	36	54	53 1/2						
73	1	162	74 1/2	105	61	19 1/4	46	46	164	31 1/2	70	31 1/2	7 1/4	-
	2				64 3/4	18 1/4	48					29 1/2		
86	1	149 3/5	80	116 1/7	66 3/5	48 4/5	52	52 1/2	151 3/5	31 1/2	60	-	18 2/5	52
	2				70 2/5	47 4/5	54	53 1/2						
87	1	162	74 1/2	114	61	19 1/4	46	48	164	31 1/2	70	31 1/2	16 1/4	-
	2				64 3/4	18 1/4	48					29 1/2		
96	1	149 3/5	80	126	66 3/5	48 4/5	52	52 1/2	151 3/5	31 1/2	60	-	20 1/2	52
	2				70 2/5	47 4/5	54	53 1/2						
99	1	163 1/2	74 1/2	117 1/4	61	18	50	50	165 1/2	31 1/2	70	27 1/2	11 3/4	-
	2				64 3/4	17	52					25 1/2		

از ارتفاع اصلاح شده (C+Z) در جدول صفحه ۶۸ و ۷۷ استفاده کنید. زمانی که واحد رطوبت زن آبی و ایرواشر انتخاب می کنید. توجه: برای پیدا کردن ابعاد " = " صفحه ۶۰ را ببینید.